

Consider these points when installing a mix bundle order of Inspire Classic Slate:

1. All mixed bundles are identical.

- a. Every bundle has the same color and size and in the same order within the individual bundles.
- b. Working from multiple bundles (two as a minimum) at the same time will help to minimize the formation of color or size patterns.
- c. Working in a “racking” method, from the corner and working out and up diagonally, will help eliminate color or size patterns.
- d. Caution should be taken when installing in a straight row, as there is a high likelihood that, if not watched carefully, a pattern running up the roof may be formed.

2. Mind your installation direction.

- a. Inspire Classic Slate may be installed from right to left or left to right.
- b. Some installers may choose to install from the center out.
 - i. This method will require very good layout of the sizing and spacing to insure the proper treatment of the edge details.

3. Watch for patterns.

- a. The creation of color or size patterns are not a manufacturing defect. Inspire has pre-mixed the parts to help the blending process on the roof.
- b. It is the responsibility of the installing contractor to insure that the desired aesthetics, as discussed between the Property Owner and the Contractor, are achieved.

4. Follow the installation guidelines.

- a. The guidelines will help make a successful installation. It is the responsibility of the installing contractor to follow the recommendations as the recommendations are the tested and proven method for the highest likelihood of success.